


# **Servicelift**

ISO - A


Bi-part. doors on serving height • Loading front and rear • Machine below • WITHOUT SAFETY GEAR

## Well dimensions are absolute min. plumbed dimensions



#### Attention:

Acceptance of machine room position to be clearified with local authorities Controller to be located in cabinet outside of shaft



machine room access

## ATTENTION:

Cabin protection reduces clear entrance openings resp. shaft sizes (see part 10)

### Accessible rooms underneath shaft inadmissible

Cabin width and -depth available in increments of 50 mm Cabin height available in increments of 100 mm

CW = cabin width min. 500 - max. 1000 mm

CD = cabin depth min. 650 - max. 1000 mm

CH = cabin height min. 600 - max. 1200 mm

DW = door width = Cabin width
DH = door height = Cabin height

SH = Serving height = lowest min. 900 mm, others min. 700 mm

SW = Shaft width = plumbed min. dimensions SD = Shaft depth = plumbed min. dimensions

HR = Headroom = clear height of top floor FFL - underside ceiling

FFL = finished floor level

FH = Floor to floor height on landing doors in line



NSW & ACT: 02 8116 1500 VIC & TAS: 03 9094 8600 QLD & NT: 07 3851 7500 WA & SA: 08 6272 9400

Modifications and errors accepted

WA & SA: 08 6272 9400

www.easy-living.com.au sales@easy-living.com.au